



## BRAKE HOUSING

- Step 1** | Secure the housing to the support provided for this purpose on the left side of the chainstay.
- Step 2** | Secure the brake housing to the left side of the brackets provided for this purpose on the down tube.
- Step 3** | Thread the brake housing on the left side of the bike.

## SPEED HOUSING

- Step 1** | Secure the rear gear housing to the brackets provided for this purpose on the right side of the chainstay.
- Step 2** | Secure the rear gear housing with a clip to the slot provided for this purpose at the front of the chainstay.
- Step 3** | Secure the rear gear housing to the brackets provided for this purpose on the right side of the down tube between the rear brake housing and the dropper housing.
- Step 4** | Thread the rear gear housing on the left side of the bike.

## SEATPOST HOUSING

- Step 1** | Thread the housing through the opening at the bottom of the seat tube. Pull out through by the opening in the dropper.
- Step 2** | Attach the dropper housing to the brackets provided for this purpose on the right side of the down tube.
- Step 3** | Thread the dropper housing on the right side of the bike.

## Kobain 29

ITEMS	#SERVICE KIT	DESCRIPTION
1	KFC03701	Rear Axle Boost148*12mm/167mm
2	KFC02101	Rubber Cable Guide
3	KFC02102	Derailleur hanger

