



BRAKE HOUSING

Step 1 | Attach the housing to the brackets provided for this purpose on the left side of the chainstay.

Step 2 | Secure the rear brake housing to the brackets provided for this purpose on the right side of the down tube between the speed housing and the dropper housing.

Step 3 | Thread the rear brake housing on the left side of the bike.

SPEED HOUSING

Step 1 | Secure the rear gear housing to the brackets provided for this purpose on the right side of the chainstay.

Step 2 | Secure the rear gear housing to the left side of the brackets provided for this purpose on the down tube.

Step 3 | Thread the speed housing on the left side of the bike.

SEATPOST HOUSING

Step 1 | Thread the housing through the opening at the bottom of the seat tube. Pull out through the opening in the seat tube.

Step 2 | Attach the dropper housing to the brackets provided for this purpose on the right side of the down tube.

Step 3 | Thread the dropper housing on the right side of the bike.

| Minus | | |
|-------|--------------|--|
| ITEMS | #SERVICE KIT | DESCRIPTION |
| 1 | KFC02101 | Rubber Cable Guide |
| 2 | KFC02102 | Derailleur hanger |
| 3 | KFC03901 | Rear Axle 216mm*12mm*1.75 OLD197mm |
| 4 | KFC03902 | Rear Axle 190mm*15mm*1.5 OLD150mm 7075 |

