



BRAKE HOUSING

Step 1 | Thread the brake housing from back to front in the chainstay straw.

Step 2 | Clip the brake hose in the middle of the pivot.

Step 3 | Thread the brake housing in the left opening of the shock plates cable organiser/spacer.

Step 4 | Thread the brake housing in the cable guide and the down tube's opening.

Step 5 | Remove the guide's cap on the left side of the down tube and fish out the housing through the upper opening.

Step 6 | Slide the anti-impact foam tube over the housing.

SPEED HOUSING

Step 1 | Thread the shifter housing from back to front in the chainstay straw.

Step 2 | Fix the housing under the chainstay and zip tie it in place.

Step 3 | Thread the housing in the right side opening of the shock plates cable organiser/spacer.

Step 4 | Thread the housing in the cable guide and the down tube's opening.

Step 5 | Remove the guide's cap on the left side of the down tube and fish out the housing through the upper opening.

Step 6 | Slide the anti-impact foam tube over the housing. Put back the guide cap.

SEATPOST SHEATH

Step 1 | Thread the dropper housing through the guide on the right side of the down tube.

Step 2 | Bring out the dropper housing through the bottom bracket. Slide the anti-impact foam tube over the housing.

Step 3 | Create a loop with the housing in order to reinsert the housing through the seat tube. Pull out the dropper cable at the end of the tube.

DJANGO CARBON 29

ITEMS	#SERVICE KIT	DESCRIPTION
1	KFC01404	CS/ST prot. kit Django Carbon
2	KFC19010	Rear Axle SuperBoost157*12mm/209.5mm
3	KFC16053	Foam Kit for Internal Routing
4	KFC01401	Pivotkit Shaft Django Carbon Black
5	KFC01402	Split pivot Carbon Shock bolt Black
6	KFC11051	Derailleur Hanger Split Pivot 12x142/148
7	KFC01405	Bearing kit Split pivot
8	KFC01403	Cable Guide kit Django Carbon

BL PIVOT

CL PIVOT

DO PIVOT

WL PIVOT

COLLAR
6 N·m

BL PIVOT
(14 N·m)

UPPER SHOCK BOLT
(14 N·m)

CL PIVOT
(14 N·m)

LOWER SHOCK BOLT
(14 N·m)

WL PIVOT
(14 N·m)

REAR AXLE
(20 N·m)

DO PIVOT
(22 N·m)

6.7 N·m

WARNING:
MAKE SURE TO
CAREFULLY READ THE
ASSEMBLY
INSTRUCTIONS AND
CLEANING
INSTRUCTIONS NOTES
ON NEXT PAGE.