



BRAKE HOUSING

- Step 1** | Thread the brake housing through the opening on the inside of the chainstay.
- Step 2** | Thread the brake housing under the lower bracket inside the frame.
- Step 3** | Remove the cap from the guide located on the down tube and pull out the housing in the center. **Do not replace the guide cap immediately**
- Step 4** | Slide the anti-impact foam tube over the housing up to the down tube.

REAR DERAILLEUR HOUSING

- Step 1** | Thread the rear gear housing through the opening at the rear of the chainstay.
- Step 2** | Thread the rear gear housing under the lower bracket inside the frame.
- Step 3** | Pull out the housing on the left by the guide located on the top of the down tube.
- Step 4** | Slide the anti-impact foam tube over the housing up to the down tube.

SEATPOST HOUSING

- Step 1** | Thread the dropper housing through the central cavity of the guide located on the down tube.
- Step 2** | Open the hatch at the bottom of the down tube to bring out the housing.
- Step 3** | Slide the anti-impact foam tube over the dropper housing up to the down tube.
- Step 4** | Make a loop with the dropper housing to reinsert it into the frame and bring it out through the seat tube. Close the hatch at the bottom of the down tube.

FRONT DERAILLEUR HOUSING

- Step 1** | Thread the front gear housing through the opening behind the seat tube.
- Step 2** | Thread the rear gear housing in the down tube to the upper right cavity of the stopper.
- Step 3** | Slide the anti-impact foam tube over the housing up to the down tube. **Replace the cap**

HATCHET CARBON

ITEMS	#SERVICE KIT	DESCRIPTION
1	KFC02201	Hanger FD w/bolts Hatchet Carb.
2	KFC02202	Hanger RD w/bolts Hatchet Carb.
3	KFC02203	Cable guides KIT Hatchet Carb.
4	KFC02204	DT Protec. KIT Open Road
5	KFC17004	Seat clamp 31.8 Blk Hatchet Carb.
6	KFC02205	Rubber Grommet KIT

