


**LEGEND**

- Brake housing
- Speed housing
- DI-2 cable
- Charging port
- Speed sensor
- Sheath outside the frame
- - - Sheath inside the frame



## BRAKE HOUSING

**Step 1** | Fix the housing to the two brackets on the chainstay using U-clips

**Step 2** | Thread the housing in the rubber cable guide's opening on the back of the motor mount.

**Step 3** | Enter the housing through the down tube and exit through the top opening on the left side. \*To make this step easier, use an internal cable guide routing kit. \*

## SPEED HOUSING

**Step 1** | Thread the rear shifter housing on the top of the downtube through the opening.

**Step 2** | Thread the housing in the opening on the back of the motor mount.

**Step 3** | Fix the housing to the three tabs located on the chainstay.

## SPEED SENSOR

**Step 1** | Attach the wire to the same guides as the brake housing on the inner surface of the base.

**Step 2** | Thread the wire through the opening at the back of the motor mount.

**Step 3** | Bring out the wire on the right side of the motor mount.

## CHARGING PORT

**Step 1** | Secure the charging port on top of the down tube.

**Step 2** | Pull the wire out through the motor opening on the right side.

## DI-2 CABLE

**Step 1** | Thread the wire through the guide at the top of the down tube.

**Step 2** | Pull the wire out through the motor opening.